selec

ō



TWIX-1-24VDC Operating Instructions

> PLC with built-in HMI

FEATURES

- Configurable LED display
- > RS485 based communication with MODBUS RTU
- protocol

48mm x 96mm

SPECIFICATIONS			
	Top Red – 8 digits (7 segment)		
Display	Bottom Green – 6 digits (7 segment)		
	8 LED's (4 Red + 4 Green)		
No. of Keys	5 (4-user configurable)		
Supply Voltage	18V - 30 VDC		
FUNCTIONAL SPECIFICATIONS (CPU)			
Programming Language	Windows based user friendly SELPRO software for ladder logic programming.		
	Program Memory : 112 kB		
Memory	Data Memory : 16 kB		
	EEPROM Memory : 2 kB		
	VAR_INOUT & VAROUTPUT TYPE Variables : - Max 120 bytes retention		
Scan Time	Typical 1ms (based on Ladder scan time)		
Function Blocks	Timer On delay, Timer Off delay, Pulse Timer, Special Timer, Up/Down Counter, PID control etc.		
Memory Retention	10 Years		

DIGITAL INPUTS					* ¹ = 90° Phase	shift signals	
Number of Digital Inputs			6 (Including 2 Fast Input)				
Operating Modes (user configurable)			Unidirectional / Bidirectional / Quadrature / Dual Unidirectional / None				
Channel			MODE				
Channel	DI	UNI	BI	QUAD	DUAL UNI	None	
FC0	10	Rate Totalizer	Rate Totalizer	1st input*1	Rate Totalizer	Digital Input	
FCU	1	Digital Input	Direction	2nd input *1	Totalizer	Digital Input	
Operating Range		5 ~ 30V DC					
Input current		3 mA @10V					
Action Level	Leve	l 1 <table-cell-rows> Level 0</table-cell-rows>	<3V DC				
ACTION Level	Leve	l 0 <table-cell-rows> Level 1</table-cell-rows>	≥5V DC				
Response Time	Digit	al Input mode	Typical 1ms (based on ladder scan time)				
		Input mode	100µsec				
Input Impedance		7.5 kΩ					
Debounce Time		0 ~ 255 ms (Default = 10 ms)					
Maximum counting Frequency (Fast Input)		5kHz					
Protection against polarity Inversions		Yes					

RELAY OUTPUTS				
Number of Relay Outputs	4			
Output Type	NO contact type			
	5A @28VDC (Resistive)			
Output Current	5A @28VDC (Resistive) 5A @240VAC (Resistive)			
Response Time	10ms (based on ladder scan	time)		
Life Expectancy	30000 operation at full load			
Isolation	No			
Existence of common points between channels	1 COM for 4 Relay Outputs			
ANALOG INPUTS				
	TC Type	RTD Type		
Number of channels	1 (user se	lectable)		
	J, K, T, R, S, C, E, B, N,			
Sensor type	L, U, W, PLATINEL II, MILLIVOLT (-5 to 65mV)	PT100		
Measurement Range	As per sensor selection	-99°C to 850°C		
Temperature Resolution	0.1°C			
Digital Resolution for MILLIVOLT	12 bits			
Input impedance in signal range	560 kΩ	750 kΩ		
Analog input error at 25°C	0.25% of full scale ±1°C	0.1% of full scale ±1°C		
Absolute input range	5V NA			
Non linearity	0.25% of full scale ±1°C 0.1% of full scale			
Conversion time	100	ms		
Protection against polarity inversion	Yes	NA		
Channel isolation	No			
COMMUNICATION				
Communication Port	RS485 Slave			
Communication Protocol	MODBUS RTU			
	9600, 19200, 38400, 57600, 115200			
Baud Rate	(user configurable via software and hardware) Default = 19200 (Preferred ladder downloading at 19200)			
ENVIRONMENTAL CONDITIONS	1			
Operating Temperature	0 to 55°C			
Storage Temperature	-20 to 70°C			
Humidity (non-condensing)	95%			
Mounting	Panel Mounted			
Weight (g)	Approx. 200gms			

A SAFETY PRECAUTIONS

This manual is meant for personnel involved in wiring, installation, operation and routine maintenance of the equipment.

All safety related conditions, symbols and instructions that appear in this operating manual or on the equipment must be strictly followed to ensure operator and instrument safety. Any misuse may impair the protection provided by the equipment.

L CAUTION : Read complete instructions prior to installation and operation of the unit.

ACAUTION : Risk of electric shock.

- procedure.





INSTALLATION INSTRUCTIONS

L CAUTION

1. This equipment, being built-in-type, normally becomes a part of the main control panel and the terminals do not remain accessible to the user after installation.

2. Conductors must not come in contact with the internal circuitry of the equipment else it may lead to a safety hazard that may endanger life or cause electrical shock to the operator.

3. Circuit breaker or mains switch must be installed between the power source and supply terminals to facilitate power 'ON' or 'OFF' function.

4. The equipment shall not be installed in environmental conditions other than those specified in this manual. 5. Since this equipment forms part of the main control

panel, its output terminals get connected to the host equipment. Such equipment shall also comply to EMI / EMC and safety requirements like CE standard

7. Thermal dissipation of equipment is met through ventilation holes provided on housing of equipment. Obstruction of these ventilation holes may lead to a safetv hazard.

8. The output terminals shall be loaded strictly as per the values / range specified by the manufacturer.

MECHANICAL INSTALLATION

Outline Dimensions (in mm)



Panel Cutout (in mm)

For installing the controller

1. Prepare the panel cutout with proper dimensions as

2. Fix the unit into the cutout. Insert the clamp from both

sides and tighten the screws.

CAUTION

The equipment in its installed state must not come in proximity to any heating sources, caustic vapors, oils, steam or other unwanted process by products.

EMC Guidelines :

1. Use proper input power cables with shortest connections and twisted type. 2. Layout of connecting cables shall be away from any internal EMI source.

MAINTENANCE :

1. To avoid blockage of ventilation holes, clean the equipment regularly using a soft cloth. 2. Do not use Isopropyl alcohol or any other organic Solvents for cleaning.

Doc. name : OP INST TWIX-1-24VDC OP595-V01(Page 1 of 2)

WIRING INSTRUCTIONS

CAUTION

Р

- To prevent risk of electric shock, power supply to the equipment must be kept OFF while wiring.
- Terminals and electrically charged parts must not be touched when the power is ON.
- 3. Wiring shall be done strictly according to the terminal layout provided in the operating manual.
- To eliminate electromagnetic interference use short wire with adequate ratings and twists of equal size.
- 5. The power supply connection cable must have a cross section of 1sq.mm or greater and insulation capacity of at least 1.5KV.

FUNCTIONAL DETAILS

TWIX-1-24VDC is a PLC with built in HMI. The user can configure the product using SELPRO software.

- SELPRO has two sections :
- Ladder logic programming section
 Selec Machine Interface, used for configuration of
- HMI.

For details of the software, please refer to the software user manual.





MENU DESCRIPTION PLC Stop mode 108 157 IX User HMI mode SEOP Internal O ENT (Press 3sec.) SET (Press 3sec.) menu mode 🕁 ENT Internal Menu UEF 12.0 Row 1 : Bootloader version 5.3 Row 2 : SELPRO Software version (Version number is subject to change) Scan time SET SEN 0 ROW1 : Ladder scan time in MS for the application downloaded. .<u>5</u>5 ROW2 : Millisecond (unit) een D Communication settings 1925 scr F1 Row1 : Slave ID and Baudrate previous 802 Row2 : Word length(8), Parity (N=None) and Stop bits (2) To configure communication settings : SET : Edit enable (Press for 3 sec.) F1 : Shift cursor position 5 F2 : Decrement value go F3 : Increment value 5 ENT : Save value ENT Ø Press **Digital Input Status** F2 d IG IERL LED Row 1 : Status of DI0/DI1/DI2/DI3 LED Row 2 : Status of DI4/DI5 **Digital Output Status** F3 d IG IERL LED Row 1 : Status of DO0 /DO1/DO2/ DO3 Enter Bootloader mode After 3sec. release Power ON No Ladder Device ENT (Pressed) Bootloader mode

ACCESSORIES (To be ordered separately)					
ORDER CODE DESCRIPTION					
AC-USB-RS485-03	USB to RS485 cable (6 pin jack for downloading)				
AC-USB-RS485-02 *	USB to RS485 cable (2 pin open wire)				
ACH-004	RJ25 (6-pin) cable				
AC-IOEXP-02	Port Expansion adapter				

Note: * Along with ACH-004 & AC-I0EXP-02 for networking

? SERVICE DETAILS

This device contains no user serviceable parts and requires special equipment and specialized engineers for repair. Please contact service center for repair on the following

numbers : Tel. No. : + 91-7498077172 ; Email : service@selec.com

NO WARRANTY ON UNIT DAMAGED DUE TO WRONG POWER SUPPLY.

(Specifications are subject to change, since development is a continuous process.)

Selec Controls Pvt. Ltd., India

Factory Address : EL-27/1, Electronic Zone, TTC Industrial Area, MIDC, Mahape, Navi Mumbai - 400 710, INDIA. Tel. No. : +91-22-4148 419/430 | Fax No. : +91-22-28471733 Toll free : 1800 227 353 (BSNL/MTNL Subscribers only) Website : www.selec.com | Email : sales@selec.com

	CALIBRA	ATION C
Model :- TWIX-1-2	4VDC	
Claimed Accuracy :-	For TC :0.25% of For RTD :0.1% o For V & I :0.5% o	f full Scal
Traceability :-		

This Units Has Been verified For All functional parameters mentioned in Operating Instruction.

Analog Parameters [For Applicable Product]

The Calibration of this unit has been verified at the following value for selection channels :-

Analog Input :-	CHO	CH1	CH2	CH3	CH4	CH5
TC						
RTD						
AI						
AV						

NOTE : Analog Input/Analog Output Has Been Verified At the following Value :

Sensor	Calibration Temp(°C)	Display Value(°C)	Sensor	Calibration Value	Display Value
К	35.0	35.0			
	700.0	700.0	Voltage (VDC)	0.000	0.000
	1350.0	1350.0	(120)	10.000	10.000
	0.0	0.0			
PT100	500.0	500.0	Current (mA)	0.000	0.000
	800.0	800.0		20.000	20.000

The thermocouple/RTD curves are Linearized in this microprocessor based product , and hence the value interpolated between the readings shown above are also equally accurate, at every point in the curve.

Product Calibration Is Traceable to NABL Standard.

Unit is accepted as accuracy is within the specified limit of claimed accuracy and certified svalid up to one year from the date of issue.

le ± 1°C lle ± 1°C ale

